




BallistiScan Software Instructions

How to install a software update.

1. Using a desktop or laptop PC, use your browser to go to <https://ballistiglass.com/support/>
2. Click on the DOWNLOAD LATEST BALLISTISCAN SOFTWARE button.
3. Save the encrypted zip file to your desktop.
4. Use an unzipping tool to unzip the archive file to your desktop.
Here is a free unzipping tool: <https://www.7-zip.org/download.html>
5. Unzip the zip archive to your desktop. The password is the PIN for the BallistiScan laptop.
6. You should now have an unzipped BALLISTISCAN vX.X* folder on your desktop.
7. Copy this folder to a removable thumb drive.
8. Bring the thumb drive to your BallistiScan PC and insert the thumb drive into the USB port.
9. Copy the BALLISTISCAN vX.X folder from the thumb drive to the BallistiScan PC's desktop.
10. On the taskbar of the laptop PC. Right click on the  icon in the taskbar.
11. Left-click on the "Unpick from taskbar" to remove icon.
12. Open the BALLISTISCAN vX.X folder that you just copied to the desktop.
13. Double click on the only executable (.exe) file with the  icon.
14. On the taskbar, right-click on the  icon.
15. Left-click on the "Pin to taskbar" option.

Now you're set with the latest version of the BallistiScan software!

*X.X is a placeholder for the latest version of the software, e.g. 2.7



WWW.BALLISTIGLASS.COM
BALLISTIGLASS LLC
PARKLAND, FL 33076 USA



(800) 960-4097
SUPPORT@BALLISTIGLASS.COM